



Air Inlet 'G' BSP. (BSIR models only)
 Entrée d'air BSP 'G' (Modeles BSIR seulement)
 Luftzufuhr 'G' BSP. (Nur BSIR modelle)



PNEUMATIC VIBRATOR OUTLINE.

29.08.2007